BRISTAN

Installation Instructions & User Guide


Please leave these instructions with the end user

SPR EFSNK Range (D3)


Specifications







Inlet Connections 1/2" BSP Flexible Tails with **Isolation Valves**




valves included)

Outlet



M24 Aerator


Pack Contents




Operation - Eco-Start



Once the handle ceases to turn, it will be supplying the maximum temperature.















Prior to Installation

All products manufactured and supplied by Bristan are safe to use provided that they are installed, operated and receive regular maintenance in accordance with these instructions.

This product needs to be installed in accordance with, and meet the requirements of The Water Supply (Water Fittings) Regulations (Northern Ireland) 2009 and The Water Supply (Water Fittings) (Scotland) Byelaws 2014. For full Installation Requirements & Notes (IRN) please visit www.wrasapprovals.co.uk/approvals-directory


Isolation valves must be fitted to the inlet water supplies to ensure ease of future maintenance.

Before installing this product the water supply must be thoroughly flushed in order to remove any swarf, solder etc. Full access must be made available for future maintenance/servicing purposes.


This product must not be modified in any way as this will invalidate the guarantee.


Spare Parts


To replace any spare parts for your tap, why not scan the QR Code or visit www.bristan.com and search for your product.



If the surface the tap is being fitted to is over 8mm; or you feel the tap needs extra stability, follow the alternative installation steps overleaf.











grub screws using the tool provided.





Your tap is now ready to use.

General Cleaning


Bristan products are made from premium materials, with hand polished. PVD, EPD or electroplated finishes.

Your tap should be regularly cleaned with warm water, a mild pH-neutral liquid soap, and polished with a soft cloth. Any residues from soap, toothpaste, shampoos and shower gels can cause blemishes if not rinsed off straight after use.


Household bleaches and cleaners contain harsh chemicals and may damage the surface finish. Avoid using abrasive cloths, scouring pads, scrub sponges, steel wool or anything similar.

Some surfaces such as nickel and pewter may be affected by the dye found in some cloths, so it is also important to avoid hanging cloths on spouts.

Maintenance - Replacing Cartridge



Alternative Installation for Surfaces Out of Tolerance/Extra Stability




Troubleshooting		
Symptom	Cause(s)	Remedy
No flow or low flow rate	Partially closed isolation valve.	Open isolation valve.
	Head of water is below the minimum distance required.	Refer to your the Specification for the minimum working pressure/distance required.
	Hot or cold water being drawn off elsewhere causing pressure changes or instantaneous boiler temperature changes.	Do not use other water outlets when using the taps.
	Airlock or partial blockage in the supply pipework or hoses.	Flush through pipework to ensure removal of debris and any airlocks.
	Water supply failure	Investigate water supply. Check your plumbing and heating systems for any faults.
Water dripping from taps	This is normal for a short time after using the taps.	This is caused by residual water tension, the build up of water in the tap body.
	If water continues to drip, possibly due to the ceramic disc valves/cartridge	Refer to the Maintenance section to replace the valves/cartridge.
Taps do not turn on	Closed isolation valve.	Open isolation valve.
	Mains water supply turned off.	Turn on mains water supply.
Wobbly Tap	Grub screws are not tight enough at the base	Ensure the grub screws are fully tightened against the base
	Extra security may be required depending on the surface the tap is fitted on to.	Refer to the Alternative Installation steps in order to fit the Reinforcing Plate.

Maintenance - Cleaning/ **Replacing Outlet**




Unscrew the aerator using M24 outlet key.



Clean and replace as necessary. Secure the aerator. Turn on the mains water supply, letting the water flow for a few minutes to flush through

the system.



Contact Us

Bristan Group Ltd.

A Masco Company



BRISTAN

Part of BRISTAN CROUP

Dordon, Tamworth

B78 1SG.

EU: Masco Europe S.à.r.l.

14 Rue Strachen 6933 Mensdorf Luxembourg

Email Us: enquire@bristan.com Website: www.bristan.com Call Us: +44330 026 6273

Our Guarantee

At Bristan, we want to make things as easy as possible for our customers. That's why we offer solid guarantees on all our products, effective from the date of purchase, to give you peace of mind.

To start your free guarantee simply scan the QR code and register your product. Alternatively visit www.bristan.com/register.

For any other gueries, please call our Customer Service on 0330 026 6273 where our expert team of advisors will be able to offer you any help and advice.

For full guarantee terms and conditions visit www.bristan.com/service-centre/guarantees.

