



**Recommended / Installation for B10  
Corner Basin.**

**Please do not tile down onto the basin.  
Tile first and then install the basin.**

*(By doing this you create extra room for the  
operation of the tap - see photograph)*

**Burlington Basin mixer T12 and T13  
are recommended to fit this corner  
basin.**