

CLEANING YOUR CARRON ACRYLIC/CARRONITE BATH



01

Each time after use, clean the bath thoroughly with warm, soapy water. We recommend simply using a small amount of washing up liquid, or a cleaner such as CIF Cream Cleaner.



02

Cleaning should be done immediately after use, whilst the bath is still warm. This way, the layer of insoluble soap, grease and dirt which would otherwise harden on the surface can be removed more easily.

After cleaning, rinse thoroughly with clean water



03

In areas with particularly hard water, insoluble calcium salts may form deposits on the taps and along the water line. In order to avoid these, clean the bath with a soft sponge and detergent in hot water immediately after use. Rinse with plenty of cold water.







Avoid leaving lit cigarettes or any other heat source on or near the surface of the bath.





Do not bring into contact with sharp-edged or pointed objects.

WARNING

Abrasive powder cleaners may scratch the surface of your bath.