



Installers Guide

Drilling Tap Holes in Acrylic Baths

- A. Apply masking tape to the area of the bath that the tap/taps are to be fitted.
- B. Using the tap manufacturer's size guide, measure and mark off the centres for the tap/taps.
- C. Before drilling, place the tap/taps over the marked centres to ensure the correct position.
- D. Use a hole saw of the correct size to suit the tap/taps purchased by drilling the **pilot holes first with light pressure.**

Tip: Blunt the lead cutting edge of the pilot drill to prevent the acrylic from cracking.

- E. Once the pilot holes have been drilled, use a hole-saw to drill out the final holes using **light pressure**, ensuring the saw does not jam, which may result in the bath cracking.