Below are the parts for CH24



Installation steps as below:

1. Insert the two pipes through the body from the bottom



2. Remove the O ring on the bottom of CH19.



3. Fit CH19 with CH24 and use Allen key to fix those 2 pipes from the bottom as below left diagram shown, then done.

