

Replacing Curvato Washers

- Unscrew the collar at the bottom of the spout and feed it gently over the spout, taking care not to scratch it.



- Untwist the spout and pull it out of the tap body.
- Replace the washers at the base of the spout.
- Insert the spout into the tap body and ensure it is firmly in place.
- Gently feed the collar over the new spout so this can be screwed into place.