

READ BEFORE INSTALLATION

In case of assistance call RAK UK **01730 237850**

BATHS

New Orient (1700 X 750), New Evolution (1750 X 750), New DKM Designer (1800 X 800), New Mistral (Left) (1700 X 900), New Mistral (Right) (1700 X 900), New Metropolitan (1700 X 700), New Metropolitan (1800X 800) and New Reserva (1700 X 800).

ONLY USE FIXINGS SUPPLIED.

Tools needed:

- Adjustable spanner
- Drill set
- Spirit level
- Tape measure
- Screw driver

Procedure:

1. Turn bath over so it is face down on the floor (protect from damage). Fix both cross supports at least in two places with screws provided (At least four screws per each support and two screws for the middle support). Fix fifth leg also in center position as per the below picture.

