

CONTOUR / IOS - Instructions

Please retain for future reference

Installation and Fitting Instructions

Before you start

Wear suitable eye protection when drilling. Take care when using power tools near water - the use of a residual current device (RCD) is recommended. Beware of hidden pipes or cables. Take care when drilling tiled surfaces as the drill might slip. Use a piece of masking tape to prevent the drill from wandering.

The unit and basin are secured to a suitably strong / reinforced wall to ensure stability. Fix in place following instructions on page 2. If in any doubt please consult an expert.

Fitting Basin

Once the basin is plumbed in finish by securing to the washstand with a silicone sealant (not supplied).

