

# Eco Function

---

The shower handsets marked with the ECO logo, shown on the right, are supplied with an optional water saving device that reduces water usage by up to 50%.



By reducing water volume but not water pressure, an invigorating shower can still be enjoyed. Simply insert the water saving device supplied between the hose and handset during installation. This device can be removed at any time if required.

N.B. Our handsets are all designed to optimise flow in very low pressure environments. In this instance it may not be necessary to use this optional device. Flow limiters give optimum performance when used on systems giving 1bar pressure or more.

