



EVENT | SQUARE HANDLE FITTING INSTRUCTIONS

Please retain for future reference

Once you have installed your Event Square Valve, you can choose between the following handle options:




To install handle levers:




Attach the handle to the temperature spindle and secure in position so that when the valve is at its hottest, the handle arm is pointing towards the 'HOT' marking on the cover plate.

Attach the handle to the flow spindle, so that when the flow is shut off the arm of the handle is pointing to the 'OFF' position.





To install cover caps:



Attach the grub screw to the spindle and secure in position. Place the cover cap on the handles to cover the holes.