

Thermostat – Manual Calibration

1. Wait 3 minutes after the last using (within this time the motor can move itself)




2. Turn out the screw and take off the motor



3. Open one outlet to measure the temperature

4. Adjust the thermo element to 38°C by hand



Thermostat – Manual Calibration



1. Disconnect and connect again the power supply
2. Wait until the motor has calibrated itself
3. Check position of top triangular fixing point in relation to bottom triangular fixing point.
4. Refit motor
5. Now make the fine adjustment of the temperature calibration in menu F2
6. Control the manual temperature setting if necessary adjust it
7. Leave the menu and test the settings

