

AFTERCARE INSTRUCTIONS

Your fitting has a high quality finish and should be treated with care to preserve the visible surfaces.

All surface finishes will wear if not cleaned correctly, the only safe way to clean your mixer is to wipe with a soft damp cloth. Stains can be removed using washing up liquid. All bath cleaning powders and liquids will damage the surface of your fitting, even the non-scratch cleaners.

GUARANTEE

All products are manufactured to the highest standards and a 5 year guarantee covers any defect in manufacture.

As gold and special effect finishes are softer than chromium plate, special care must be taken when cleaning, a 3 year guarantee covers these finishes.

NOTE: The 5-year guarantee on the cartridge is invalidated if damaged by any waterborne debris.

In the interests of continuous product development we reserve the right to alter specification as necessary

PRODUCT CODE: W CL C /G 1, 3

PRODUCT IDENTIFICATION CODE LASER ETCHED ON PRODUCT

Installer please fill in code here _____.

TELEPHONE HELPLINE! +44 (0)844 701 6273

Bristan Group Limited
Birch Coppice Business Park
Dordon
Tamworth
Staffordshire
B78 1SG
UK
A Masco Company
Website: www.bristan.com
Telephone: +44 (0) 844 701 6274
Facsimile: +44 (0) 844 701 6275
Email: enquire@bristan.com

BRISTAN

Cistern Lever (W CL C/G 1,3)

Fitting Instructions

Please keep these instructions for future reference and request of replacement part

INSTALLATION

N.B. Before installation, please write the name and product code of your fitting in the spaces provided overleaf. This will ensure a speedier service if you should need to phone the helpline.

1. Identify all components and check for completeness.
2. Remove cistern lid.
3. Loosen lifting arm retaining screw and remove lifting arm from handle shaft.
4. Disconnect lifting arm from the siphon plunger hook.
5. To remove the old handle, loosen and remove back-nut from the handle shaft. It may be necessary to remove a split pin from the shaft first. Pull handle from cistern.
6. To fit the new handle, remove lifting arm and plastic snap-ring from the handle shaft and the plastic back-nut from the threaded sleeve.
7. Remove threaded sleeve from handle shaft and mount in cistern using plastic back-nut. Tighten firmly.
8. Insert handle shaft through sleeve and replace snap ring.
9. Connect plunger hook to lifting arm in the appropriate hole so that when lifting arm is mounted on handle shaft it is directly above the siphon plunger.
10. Tighten retaining screw on lifting arm.
11. See over the page for aftercare instructions.

www.qssupplies.co.uk

COMPONENTS

1. Handle
2. Handle Shaft
3. Threaded Sleeve
4. Plastic Back-nut
5. Plastic Snap-ring
6. Lifting Arm
7. Lifting Arm Retaining Screw

