

Bath Screen Information

Screen is not designed to fit on baths with stepped fronts, roll top rims or integral soap dishes. Fitting of screen on baths which have a raised head rest or shape is not recommended. Screen must not be impaired by bath handles.

Ionic Bath Screens are not designed to fit on baths with stepped fronts, roll top rims or integral soap dishes.

Fitting of screen on baths which have raised head rests or shapes is not recommended.

There must be no items causing obstruction with the seal and bath, as any of the above may cause leaks.

When choosing your Bath Screen, please ensure that if your bath has bath handles, that they do not interfere with the bath rim area where your screen will be placed.

When choosing an in-swing or folding Bath Screen, please ensure your swing area is not interfering with any brassware or internal shower features. Similarly, when choosing an out-swing, please ensure the out-swing area is free from any obstructions.

The Ionic Panel Hinged Bath Screen is handed so please ensure you state whether you require a right or left handed configuration when ordering.

Ionic Bath Screens are suitable for standard pressure showers and are not recommended for use with power showers. It is recommended that the shower head position is situated on the same wall to which the Bath Screen is fixed and in the centre of the shower area.