

CURVED SCREENS


Installation Instruction

4856 02/10
EE72691967


CONTENTS OF CARTON

Please check you have everything listed below before installation commences

Note:
Before installation check all walls are sound and tiles are secured.



Ref. No.	Description	Qty
1	Compensating profile	1
2	Screen glass and adjuster profile	1
3	Cover member	1
4	Screen bottom carrier seal	1
5	Flap seal 20.5mm	1
6	Flap seal 16.5mm	1
7	Fixing pack	1



SAFETY PRECAUTIONS

We strongly recommend that protective packaging along the glass edges is kept on place for as long as possible to prevent damage before installation




Protective footwear when lifting panels



Safety glasses when drilling

TOOLS REQUIRED



Drill



Crosshead screwdriver



Silicone & gun



Pencil



Knife



Spirit level



Hacksaw



Allen keys

Figure 1

PRODUCT ASSEMBLY DIAGRAM




Figure 2

COMPONENTS FOR PRODUCT ASSEMBLY





CURVED SCREEN PARTS				FIXING PACK			
Ref.	Component	Description	Quantity	Ref.	Component	Description	Quantity
1		Wall profile with seals	1	15		Bottom injection moulding	2
2		Wall clamp profile with seals	1	16		No. 10 x 50mm crossed recessed countersunk self tapping	4
3		Cover profile	1	17		I/D 4mm x O/D 12mm x 1mm washer	7
4		Curved screen	1	18		No. 8 x 13mm crossed recessed panhead screw	3
5		Casting LH hinge support	1	19		8mm wall plug	4
6		Casting RH hinge support	1			3,25mm drill bit	1
7		Flat CAM B	1	20		14mm levelling spacer	1
8		Rise and fall CAM A	1			Rise and fall cam	1
9		No. 6 x 25mm S/T countersunk screw	4	21		wall cover profile top cap LH/RH	1
10		Bottom seal	1	22		Injection moulding end cap LH	1
11		16,5mm flap seal	1	22		Injection moulding end cap RH	1
12		20,5mm flap seal	1				
13		Flexible hinge support seal	1				
14		Brush hinge support seal	1				

Figure 3

CHANGING SCREEN FROM LEFT HAND TO RIGHT HAND

**ALL SCREENS ARE
SUPPLIED LEFT HANDED**

Screen as supplied, Figure 4.




Figure 4

If you require a right hand installation the screen can be altered as follows:

- a) Remove screws at one end only, Figure 4a.




Figure 4a

- b) Lift off end casting, keep plain white moulding located on the screen as shown, Figure 4b.




Figure 4b

- c) Lift off screen, Figure 4c.







Figure 4c


Take the bottom cam out of the screen member and discard it. Take the plain cam out of the top of the screen member and put it into the bottom of the screen member. Take the cam out of the fixing pack and place it into the top of the screen member.



Fit screen into end casting as shown, Fig. 5b.



Push end casting into place on screen, Fig. 5c.



Turn screen upside down.

Position and tighten screws,
Figure 6a.

Turn screen upside down,
Figure 6b.




Figure 6a




Figure 6b

Figure 6c

CURVED BATH SCREENS

1. To position the compensating profile on to the bath use the table provided.

Using a spirit level mark the 4 fixing positions. Drill and plug the holes, (Fig 7).

Fix the wall profile to the wall using 4 of No. 10 x 2" counter sunk self tapping screw.

Note: The wall fixings and screws supplied are suitable for solid wall construction. Substitute for suitable fixings as appropriate.



Warning:
Aluminium Profile
may scratch the bath.
Take care when Installing.






Figure 7

2. Slide the Hinge support member into the wall until it is level with the widest face of the wall profile, (Fig 8a).

Using the levelling spacer make sure there is a 14mm gap between the bath rim and the screen glass. (Fig 9).

Drill through the holes in the wall profile using the 3.25mm drill bit, and into the screen member.

Fit the 3 No. 8 x 13mm self tapping screws and washers into the 3 positions in the screen member. (Fig 8b).




Figure 8a






Figure 8b




Figure 9

3. Remove 14mm spacer and attach the seal to the glass with the deflector pointing into the bath.

Cut off any excess seal with a hacksaw.

Cut the seal level with the end of the screen glass.

Fit the suitable flap seal making sure that it touches the rim of the bath but still allows the screen to open and close comfortably.

Push the end cap into the exposed end of the seal, (Fig. 10).

Fix into position using a small amount of waterproof sealant.

Take the screen handle out of the fixing pack and unscrew it apart. Insert the handle with stud bar through the glass and tighten it up to the other side.

Make sure there is a gromet separating the stud bar and the glass.

Rub silicone grease around bottom cam to prevent limescale build-up.






Figure 10

4. Clip the aluminium cover member onto the side of the aluminium wall profile.

Fit the top cap to the aluminium profile by selecting the correct handed cap.


Wet the bottom of the cap and push it into position, (Fig 11).


Apply waterproof sealant along the outside edge of the profile and along the bottom as indicated.



Ensure screen is fitted correctly before applying clip on cover.

It is difficult to remove once fitted.





CUSTOMER CARE HELPLINE
0870 1296085
CUSTOMER CARE FAX LINE 01482 499611

We pursue a policy of continuing improvement in design and performance of our products.
The right is, therefore, reserved to vary specifications without notice.

