

USER MANUAL



Table of contents

For your safety	3
Who is this product suitable for?	3
How is this product used?	3
Misuse	3
Technical data and conformity	3
Technical data	3
Declaration of conformity	3
Getting to know your product	4
The product at a glance	4
Using the power socket	4
How to use the product	5
Switching the mirror cabinet on and off	5
Care instructions	6
General care instructions	6
Care instructions for mirror surfaces	6
Cleaning surfaces	6
Care instructions for power socket elements	6
Cleaning the surface	6
Disposal	7
Disposal of old electrical and electronic equipment	7

For your safety

Who is this product suitable for?

The mirror cabinet is suitable for use by all age groups. Children must be shown how to handle and operate it the first time they use it.

How is this product used?

The product is suitable for the following application purposes:

- storing cosmetic and hygiene items
- adapting lighting conditions in bathrooms

Misuse

Geberit accepts no liability for the consequences arising from misuse.

Technical data and conformity

Technical data

Nominal voltage	230 V AC
Mains frequency	50 Hz
Protection degree	IP44
Protection class	II
Light colour	4200 K
Plug type	BS 1363 A
Power socket mains voltage	230 V AC

Declaration of conformity

You can obtain a copy of the declaration of conformity from your responsible Geberit sales company.

Getting to know your product

The product at a glance




Figure 1: Geberit Option




Figure 2: Geberit Option Plus

- 1 Top light strip
- 2 Bottom light strip
- 3 Button to switch top light strip on or off
- 4 Button to switch bottom light strip on or off

Using the power socket

The internal power socket is suitable for razors.

Only devices with a mains voltage that is compatible with the power socket's mains voltage may be used. The mains connection must be compatible with the mains plug. → See "Technical data", page 3.


How to use the product

Switching the mirror cabinet on and off

Prerequisite


- Depending on the mirror cabinet model, the buttons may be the opposite way round to those shown in the figure.

1 Press the button on the right.



- ✓ The bottom light strip switches on or off.

2 Press the button on the left.



- ✓ The top light strip switches on or off.

Care instructions

You have selected a product with a high-grade surface. Please follow the care instructions below.

The manufacturer does not assume any liability for product damage that arises as a result of incorrect care and handling.

General care instructions

- Never use cleaning agents that contain chlorine or that are acidic or corrosive.
- Never use cleaning agents that are abrasive or may scratch the surface.
- Never use sharp or pointed objects when cleaning.
- Make sure that an efficient source of ventilation and an appropriate room temperature are present in your bathroom.
- Protect the surface from bleaching due to extreme light and sun exposure.

Care instructions for mirror surfaces

Please note the following when cleaning mirror surfaces:

- Use glass cleaner.
- Use a chamois leather or a soft, lint-free cloth.
- Remove drops from the edges of mirror surfaces immediately.

Cleaning surfaces

1 Clean the surfaces. Please follow the corresponding care instructions.

2 Dry the surfaces with a soft, lint-free cloth.

Care instructions for power socket elements

Please note the following when cleaning power socket elements:

- Use mild liquid cleaning agents and water.
- Use a soft, lint-free cloth.

Cleaning the surface



WARNING

Danger of fatal electric shock
Incorrect cleaning can lead to death or serious injury.

- ▶ Disconnect the power supply before cleaning.
- ▶ Allow all of the surfaces to dry completely before the power supply is permitted to be switched back on.

1 Clean the surfaces. Please follow the corresponding care instructions.

2 Dry the surfaces with a soft, lint-free cloth.

Disposal

Disposal of old electrical and electronic equipment



In accordance with Directive 2012/19/EU (WEEE - Waste Electrical and Electronic Equipment) manufacturers of electrical equipment are obliged to take back old equipment and to dispose of it appropriately. The symbol indicates that the product cannot be disposed of with non-recyclable waste. Old equipment should be returned directly to Geberit where it will be disposed of appropriately. Addresses to which equipment can be returned can be requested from the relevant Geberit sales company.



Geberit International AG
Schachenstrasse 77, CH-8645 Jona
documentation@geberit.com
www.geberit.com