

Tools & Material Required

- Tape measure
- Electric drill
- Masonry drill bit - 8mm diameter
- Spirit level
- Stepladder (for taller radiators)

Key	Component	Qty
A	Bracket Post	4
B	Spacer	4
C	Wall Plug	4
D	Bracket	4
E	Screw - 6mm dia x 50mm	4
F	Washer	4
G	Grub Screw	4
H	Allen Key	1

Assembly Instructions

- Screw bracket posts (A) & spacers (B) onto studs on the rear of the radiator.
- Accurately mark out bracket holes on wall using spirit level.
- Drill four 8mm diameter holes to a minimum depth of 65mm & insert wall plugs (C).
- Screw brackets (D) into wall plugs (C) with screws (E) & washers (F).
- Slide bracket post (A) on radiator into bracket (D) and secure in position by tightening grub screw (G) with allen key (H).

Electric radiators should be fitted only by a qualified electrician and must be earthed and connected to a cable outlet in the bathroom in accordance with I.E.E. wiring regulations. The electrical connection should be made to a '5 amp fused fixed spur' located outside the bathroom.

Note: for maintenance purposes, cable outlets must remain accessible and cables must not be buried directly into walls.

