

Tools & Material Required

Tape measure
 Screwdriver - crosshead
 Pliers
 Electric drill
 Masonry drill bit
 Spirit level
 Stepladder (for taller radiators)

Key	Component	Qty
A	Boss	4
B	Wall Plug	4
C	Bracket	4
D	Screw, 6mm dia x 50mm	4
E	Washer	4
F	Grub Screw	4
G	Allen Key	1

Assembly Instructions

Screw bosses (A) to studs on the back of the radiator.
 Accurately mark out bracket holes on wall using spirit level, to dimensions as shown on Technical Data Sheet.
 Drill four holes to a minimum depth of 65mm & insert wall plugs (B).
 Attach brackets (C) to wall with screws (D) & washers (E).
 Hang radiator onto wall by inserting bosses (A) into brackets (C).
 Tighten grub screws (F) with Allen key (G).

Electric radiators should be fitted only by a qualified electrician and must be earthed and connected to a cable outlet in the bathroom in accordance with I.E.E. wiring regulations. The electrical connection should be made to a '5 amp fused fixed spur' located outside the bathroom.

Note: for maintenance purposes, cable outlets must remain accessible and cables must not be buried directly into walls.

