


Inline Sliding Recess




INSTALLATION INSTRUCTIONS

www.aquadart.co.uk

Please read through the complete instruction leaflet before commencing any installation work!





IMPORTANT


This product should be installed by a suitably qualified and proficient person. The fitting instructions should be followed carefully to ensure a proper and safe installation. Failure to follow these instructions could result in future injury.

These instructions and list of parts assume that installation is done against solid/tiled walls.

Please check this product for damage prior to starting the installation. No claims can be made after the product has been fitted.

PLEASE NOTE :The minimum and maximum adjustment sizes noted on the product brochures are based on perfectly plumb walls and trays.

COMPONENTS AND BOX CONTENTS





Box Contents

SN	Description	Image	Qty	SN	Description	Image	Qty	SN	Description	Image	Qty
1	Top Rail Profile		1	12	Fixed Panel A		1	23	End Cap Outside Part		4
2	Bottom Rail Profile		1	13	Fixed Panel B		1	24	Glass Clip		4
3	Wall Profile		2	14	Door Panel		1	25	Screw Cap		4
4	Cover strip		2	15	Screw ST 4*30		6	26	Runner	9	4
5	Vertical Profile		2	16	Screw M5*22		4	27	Soft Close Buffer		4
6	Wall Plug	B	6	17	Screw M5*15		2	28	Handle		1
7	Vertical Seal A		1	18	Screw ST 4*12		8	29	Cover Clip		10
8	Vertical Seal B		1	19	Screw M4*12		8				
9	Vertical Seal C		1	20	Wall profile Top Cap		2				
10	Rail Seal A		2	21	Vertical profileTop Cap		2				
11	Rail Seal B		2	22	End Cap Inside Part		4				

FIXING KIT COMPONENTS, SITE CONDITIONS

FIXING KIT





IMPORTANT - Missing Components


Please check this product for missing components prior to installation.

For spare parts visit www.aquadart.co.uk

IMPORTANT - Installation site

- 1. Ensure the top surface of the shower tray on which the enclosure will be installed is level in every direction.
- 2. The tiles or other wall finishing should be effectively sealed at tray edges.
- 3. Tiles should extend at least to the corner of the tray and a minimum of 1.9 meters from the top of the tray.

PROCEDURE




TRAY MUST BE 100% LEVEL IN ALL DIRECTIONS

Ensure the shower tray is level in all directions and is properly sealed to the wall. The wall must be tiled down to the top edge of the tray. **Do not angle out bottom tile.**

TRAY MUST BE SEALED FULLY AROUND WHERE THE TRAY MEETS THE WALL.

INSTALLATION INSTRUCTIONS


Step.1 Fix the wall profiles onto the wall.





- Step.1 Place the wall profile to the wall(roughly 10mm away from the front of the tray).(Diagram 1.1).
- Step 1.1 Level the profile using a spirit level. Once you are happy that the profile sits on the tray, correctly mark the wall through the 3 pre-drilled screw holes in the wall profiles(no.3).


 NOTE: You may find it easier to mark and drill the wall if you apply masking tape to it first.
- Step 1.2 Remove the wall profiles and drill the marked points using an 6mm masonry drill bit, once this is done insert $3 \times$ wall plugs(no.6).
- Step 1.3 Fix the wall profile (no.3) to wall using the screws ST4x30(no.15).
- Step 1.4 Fix another wall profile on to the wall in the same way above.



Step 1.2


INSTALLATION INSTRUCTIONS

Step.2 Fit the fixed panel and rail profile.




INSTALLATION INSTRUCTIONS

Step.3 Secure the fixed panel and rail profiles.



Step.3.1 Ensure the fixing holes on the top and bottom rail profiles line up with the holes on the fixed glass panels by adjusting the rail profiles and the fixed glass panels. Secure together the rail profiles and the glass using the screws M5 x 15(no.17)


INSTALLATION INSTRUCTIONS




- Step 4.1 Insert the rail profile end caps into the rail profiles(Diagram a/b).
- Step 4.2 Secure the end caps(no.22/23) using the screws M5x22 onto the rails, once this is done press the cover caps(no.25) onto the end caps fixing holes.
- Step.4.3 Drill 4 equally spaced holes with 3mm drill bit through each wall profile into the vertical profile then fit the vertical profiles to the wall profiles using the screws ST 4 x 12(4pcs for each wall profile).

INSTALLATION INSTRUCTIONS

Step5. Fit the door panel



INSTALLATION INSTRUCTION



Step 6.1 Fit the shorter vertical seal(no.7 short soft edge) onto the larger fixed panel. Fit the longer vertical seal(no.8 short soft edge) onto the door panel. Fit the vertical seal(no.9 long soft edge) onto the small fixed panel.

Step 6.2 Fit the handle onto the door panel, ensure the clear washer has been placed between the glass and handle.

Step 6.3 Place the top caps onto the wall profile.



DO NOT USE THE ENCLOSURE FOR 24 HOURS AFTER SEALING

Applying Silicone Sealant

Sealing Inside

Seal from the top of the wall profile to the bottom on the INSIDE between the wall profile and the wall.

IMPORTANT: Do not apply sealant on inside of the tray. **Sealing Outside**

Seal from the top of the wall profile to the bottom between the wall profile and tiles on both sides. Also seal along the bottom where the frame meets the tray. Seal the joints between the bottom profile and any upright profiles.

AFTERCARE

Cleaning Instructions

It is important to clean your Aquadart shower enclosure after every use. Please wipe down all glass and metal parts with a clean soft cloth. Ensure that all residual water on the glass is removed after every use.

Usage

For reliable, watertight performance from your Aquadart enclosure your shower head should not be positioned so that the shower sprays directly onto the enclosure door. Failure to comply with this may cause the shower to leak. Outward opening doors may cause water to drip onto the floor, please ensure that the floor covering immediately outside the enclosure will not be affected by water.







This product has been treated with Clean & Clear™ easy clean glass treatment, a protective barrier which creates a 'non-stick' surface on your glass, helping to resist lime scale build up and water spots. For further information on Clean & Clear™ please visit www.aquadart.co.uk

Aftercare

Clean & Clear ™ glass can be cleaned with any suitable nonabrasive glass cleaner - with PH value of between 3-11; the coating will not be damaged. Avoid surfactants and heavily perfumed products. Vinegar and water based products are very effective. Do not use abrasive scrubbing cleaners or equipment for cleaning.

Warranty

Limited 5 year Warranty for Clean & Clear™ treatment: To guarantee treated surfaces will remain more repellent than untreated glass for 5 years from start of use, as long as basic manufacturer maintenance recommendations are followed and no harsh or abrasive cleaners are used.

